




Sony Vaio VPCW21FX Battery Replacement

If your laptop will not power on or keep its charge, you may need to replace the battery. To replace it follow these steps.


Written By: Alexis




INTRODUCTION

Is your laptop dying at a rapid pace no matter what you do? Replacing your battery takes virtually no time and is done in only a few steps. No tools are required and anyone can replace the battery.

Step 1 — Battery




 Make sure your device is powered off and unplugged to avoid electric shock.


- Place your device upside down with the bottom panel facing upwards.
- Orient the device so the battery is away from you as shown

Step 2



- Unlock the battery by sliding the lock switch to the right.
 - Locate the release latch. Slide the latch to the left to remove the battery from your laptop.
-  Be sure to lift up on the battery while you slide the latch to the left.

Step 3



- Remove the battery from your laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-01 09:39:26 AM.